

MTG3000 VoIP Trunk Gateway User Manual v1.0



Dinstar Technologies Co., Ltd.

Address: 9th Floor, Guoxing Building, Changxing Road, Nanshan District, Shenzhen, China

Postal Code: 518052

Telephone: +86 755 61919966

Fax: +86 755 2645 6659

 $\pmb{Emails}{:}\ sales@dinstar.com, \ support@dinstar.com$

Website: www.dinstar.com

Welcome

Thanks for choosing MTG3000 Trunk Gateway! We hope you will make optimum use of this flexible, rich-feature trunk gateway. Please read this document carefully before install the gateway.

About this manual

This manual provides information about the introduction of the gateway and about how to install, configure or use the gateway.

This manual is written with reference to the default configurations of the MTG3000 Trunk Gateway.

Intended audience

This manual is aimed primarily at network and system engineers who will install, configure and maintain the gateway.

System engineers are persons who customize the configurations to meet the requirements of users.

Parts of this document are aimed at users who will actually use the gateway.

Revision Records

Document Name	MTG3000 Trunk Gateway User Manual v1.0
Document version	V1.0
Firmware version	2.05.03.03
Revised by	Ivanka Yuan
Date	March 3, 2016

以上内容仅为本文档的试下载部分,为可阅读页数的一半内容。如要下载或阅读全文,请访问: https://d.book118.com/80716506515
2006110